

CARE & MAINTENANCE IMPORTANT SAFETY INSTRUCTIONS Read and adhere to the safety instructions provided in this manual to prevent accidents, electric shock, or damage to the iron. • Proper Handling and Usage • Use the travel steam iron according to the instructions • For a better product experience, please drain out excess water from the water tank after using it. If the water is stored for a long time, it will go bad and provide an environment for bacteria to grow. It is recommended to let the steam flow for about 30 seconds after you finish ironing to empty the water inside the heating element and then drain the water inside the water tank. • The iron is suitable to be used with tap water. However, if you live in an area with hard water, we recommend that you mix an equal amount of tap water with distilled or demineralised water. This will prevent fast-scale build-up and prolong the lifetime of the iron. • Store the iron in a dry place and avoid direct sunlight to prevent discolouration.	TROUBLE SHOOTING PROBLEM • The iron is not heating up. PROBABLE CAUSE • The iron is not plugged in properly or the switch is not on. SOLUTION • Check if the iron is plugged in properly and if the switch is on. PROBLEM • The iron is not producing steam. PROBABLE CAUSE • The iron is not plugged in properly or the switch is not on. • The iron has not heated sufficiently. • The steam on/off button is not on. • The water level in the water tank is too low or it has all been used up. SOLUTION • Check if the mains plug is inserted properly and if its wall socket is working. • Check if the iron is switched on. • Let the iron heat up ≈20 seconds. • Press the steam on/off button. • Unplug the iron and refill the water tank. • Use the iron vertically, wait for a few seconds for the steam to be released.	PROBLEM • Water droplets drop from the iron steamer head. PROBABLE CAUSE • The iron has not been fully heated up. SOLUTION • To allow the iron to fully heat up by waiting for a few seconds. PROBLEM • The iron produces a pumping sound / the handle vibrates. PROBABLE CAUSE • Water is pumped to the steamer head to be converted into steam. SOLUTION • This is normal. • Unplug the iron and refill the water tank. PROBLEM • Leakage from the water tank. PROBABLE CAUSE • The cover of the water inlet is open. SOLUTION • Properly seal the water inlet cover.	SAFETY INSTRUCTIONS Read and adhere to the safety instructions provided in this manual to prevent accidents, electric shock, or damage to the iron. • This iron is intended for household use only. • Only connect the iron to an earthed wall socket. • Check the main cord regularly for possible damage. • Fully unwind the mains cord before you plug it into the wall socket. • DO NOT immerse the iron in water or any other liquid, nor rinse it under a tap. • Do not use the iron if the plug, mains cord or the iron itself shows visible damage, or if the iron has been dropped or leaks. • The iron must not be left unattended while it is connected to the supply mains. • This iron can be used by children aged from 12 years or above and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the iron in a safe way and understand the hazards involved. • Children shall not play with the iron. • Cleaning and user maintenance shall not be made by children without supervision. • Keep the iron and its cord out of reach of children less than 12 years of age when the iron is switched on or cooling down. • Do not let the mains cord come into contact with the hot steamer head.	CLEANING & STORAGE INSTRUCTIONS • Please clean the massager with a clean dry cloth. • Ensure that the device is turned off before cleaning the pads / display panel. • Do not dis-assemble the device. • Please store the massager in a clean dry space. Do not expose to extreme heat or cold. The ideal environment to store is 5°C to 40°C at ≤80% humidity. • Store away from direct sunlight or corrosive gases. CUSTOMER SUPPORT For assistance, please feel free to reach out to our customer support team. Email - support@xech.com Whatsapp - +91 88288 44466 xechofficial xech.in xechtechnologies Xech Technologies xechofficial xechofficial	SCAN TO REGISTER WARRANTY Purchasing Date: Invoice No: Dealer information: This product should not be put / thrown away with regular trash at the end of its useful life. It must be disposed at a central point for recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging is meant to warn you. The materials used in this appliance can be recycled.	WARRANTY XECH warrants that the product will be free from any manufacturing defects & takes responsibility in case the device fails to function for a period of one year from the date of the original invoice. The warranty period validity is also subject to the following conditions: • The customer has to register the warranty for the production https://xech.com/pages/warranty within 15 days from the date of purchase. • The product is not given to some external repair personnel. • It is only valid in the Indian Subcontinent. • If the device is not immersed in water. It also does not cover natural wear & tear or rough usage. • If the instruction manual is not followed & the device is not used in an improper manner. • If the device is not used for its stated functionality. • If the device is not used by children below 3 years or someone incapable or using the device. • The customer can claim warranty by visiting our website www.xech.com or contacting our customer support team.	XECH JETSTEAM Foldable Garment Steamer User Manual	
xechem.com 10	xechem.com 11	xechem.com 12	xechem.com 13	xechem.com 14	xechem.com 15	xechem.com 16	xechem.com 17	xechem.com 18
INDEX Thank You.....02 Our Vision.....03 Description.....04 Specifications.....04 Product Features.....05 Safety Features.....05 Applications.....06 Product Guide.....07 Operating Guide.....08 Care & Maintenance.....10 Trouble Shooting.....11 Safety Instructions.....13 Cleaning & Storage Instructions.....15 Customer Support.....15 Warranty Registration.....17	Thank You! For choosing our product	OUR VISION We believe in Technocracy & that the world can become a happier & better place with the power of technology & design! Most brands are focusing on profit, we focus on technological happiness to change the world. XECH was founded 2018 Launched exclusive range of consumer electronics 2020 Launched India's 1st stethoscope sterilizer 2020 1st brand under Amazon's Emerging Brand Days 2021 Sold 20,000+ units of eye massagers across India 2022 Introduced new range of portable home & kitchen appliances 2023	DESCRIPTION XECH Jetsteam is a compact and lightweight garment steamer iron that is designed for travel. It features a foldable design, & a powerful heating element that allows instant steam generation, and even heat distribution & continuous steam flow for efficient ironing. Jetsteam's humanised form factor allows easy manoeuvrability for vertical ironing across various fabrics, including cotton, wool & denim. Whether you're jetting off on a business trip or exploring new destinations, Jetsteam is always there for a pristine & fresh look! SPECIFICATIONS Wattage - 1200 Watts Voltage - 220v Steam Discharge - 20C / Minute Water Tank Capacity - 150ml	PRODUCT FEATURES Instant Steam Generation Horizontal & Vertical Steaming Foldable Design Dense Steam Easy Refill Mechanism	APPLICATIONS Garments Pillows Bed Sofa Chairs *Garments - (Cotton, Wool, Plush, Linen, Silk, Denim)	PRODUCT GUIDE 1 2 3 4 7 6 5 9 8 1 2 3 4 7 6 5 9 8 1 2 3 4 7 6 5 9 8 1 2 3		